

GAZELLE INSTRUCTIONS



NOT A TOY. ADULT SUPERVISION REQUIRED

- PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING
- RECOMMENDED FOR CHILDREN AGE 5 YEARS AND OLDER
- MISUSE OR CARELESS USE MAY CAUSE INJURY OR DEATH
- DO NOT USE ANY ARROWS OTHER THAN THOSE RECOMMENDED FOR THIS BOW


FOR MAXIMUM SAFETY AND ENJOYMENT, ALWAYS EXERCISE CAUTION, COMMON SENSE AND SAFETY RULES WHEN SHOOTING THE BOW.

FOR YOUR OWN SAFETY

- EYE PROTECTION STRONGLY RECOMMENDED
- DO NOT POINT AT ANYTHING OTHER THAN YOUR INTENDED TARGET
- NEVER DRY FIRE YOUR BOW (FIRING WITHOUT AN ARROW)
- CHECK ARROWS REGULARLY FOR ANY DAMAGE SUCH AS CRACKS, SPLITS, SPLINTERS.
- IF ANY DAMAGE IS FOUND, THE ARROW MUST BE DESTROYED
- ALWAYS USE AN APPROPRIATE BACKDROP FOR MAXIMUM SAFETY. IT MUST BE CONSTRUCTED OF A DURABLE MATERIAL AND BE CONSIDERABLY LARGER THAN THE TARGET. THE SIZE DEPENDS ON THE ACCURACY OF THE USER. INCREASE THE SIZE OF THE TARGET IF YOU REQUIRE.
- WHEN SHOOTING AT THE TARGET ALWAYS HAVE A CLEAR VIEW OF THE TARGET AND BEYOND. TO BEGIN WITH THE SHOOTER SHOULD START NEARER TO THE TARGET, THEN AS THEIR ACCURACY IMPROVES MOVE FURTHER BACK.

STEP I: STRINGING THE BOW.

Attach the string by looping the ends around the upper and lower tip.



**PLEASE KEEP THESE INSTRUCTIONS
SAFE FOR FUTURE REFERENCE**


Arrow Precision, LLC
1619 W. Washington Street
Allentown, PA 18102

Tel: 610 437 7138
Fax: 610 437 7139
Email: sales@arrow-precision.com
Web: www.arrow-precision.com

STEP 2: BEFORE SHOOTING THE BOW

The arm guard

Please use the arm guard as shown. This will protect you from the string grazing your arm when the string is released.



ARM GUARD POSITION

The finger tab:

Firstly attach the finger tab on the palm side of the hand used to draw the bow.

The finger tab included with the bow protects from rubbing by the bow string when it is released. It is worn by slipping it on over the second and third finger of your hand.




FINGER TAB

STEP 3: THE ARROW

Check your arrow before each shot. The nock of the arrow **MUST** be positioned so the index vane (odd color vane) faces away from the string. The point of the arrow will be in front of the user facing the target.

NOCKING THE ARROW


Rest the arrow against the top of the handle of the bow as shown. The nock of the arrow should be tight against the string. The arrow should be at 90 degrees to the string.



STEP 4: SHOOTING THE BOW

Hook three fingers on the string. The fore finger above the arrow and middle and ring finger below the arrow.

Draw the bowstring back to your jaw, your fore finger should be positioned at the corner of your mouth. This position is referred to as the anchor point.



HOLDING THE ARROW

Stand at a right angle to the target. If you are a right handed user, position your left shoulder towards the target. Your shoulders should line up with an imaginary line drawn from the center of the target.

A comfortable stance is important. Aim at the intended target, making sure it is safe, then release the string.

Never draw back and release your bow without an arrow in place.

SHOOTING
THE BOW

